

ADMINISTRATOR OPERATIONAL GUIDE



A

Tip-Up Armrests

To adjust the height use the roller adjuster found on the bottom of the armrest. They can be tilted all the way up when they are not needed.

B

Seat Back Angle Adjust

To adjust the backrest rotate the knob forward to bring backrest forward, and turn in opposite direction to move backward.

C

Seat Height Adjust

Simply pull upward on the handle closest to the backrest of the chair. Then apply weight to make it go down and sit up to make higher. When you reach your desired height let go of the handle.

D

Tilt Rocker Adjust/Lock

To adjust the tilt of your chair lift the middle lever, then push back on the backrest for desired position. Push down on the lever to lock the tilt angle if desired.

E

Air Lumbar

To increase lumbar support simply pump the bulb on your left side to desired level. To release lumbar support simply push the little black button.

F

Weight Adjust/Rocker Tension

Turn the round dial located at the front on your right side. Turn it clockwise to increase tension and counter-clockwise release tension.

G

Front Tilt Adjust

Simply turn the little handle found under the left side of the seat cushion, clockwise to floor to make the cushion go down or turn it counter-clockwise to make the cushion go up.

H

Adjustable Headrest

Firmly grip the headrest, then pull up or push down for your desired height.

SCAN FOR
GUIDES



Guides also available at:
<https://www.ultraseat.com/downloads>

15002101

UPDATED: 30/11/23

Call Support 1-800-667-7328

www.ultraseat.com

inquiries@ultraseat.com