

KAB SERIES ARMRESTS

INSTALLATION GUIDE

KAB SERIES ARMRESTS

- KAB Series



Phone: 1-800-667-7328
Fax: 1-888-667-7328
www.ultraseat.com



ULTRA SEAT CORPORATION

**Product in photo(s) may be different than purchased product,
For additional photos and information please visit
www.ultraseat.com*

1

To locate the weld nuts, push firmly on the seat side about 3" above the recline handle. (The other weld nuts are 1.5" from the first hole.)



2 Bolts, 2 Lock Washers, & 2 Spacers required for KAB Series mounting.

2

Using a sharp blade, carefully puncture the seat fabric for each hole. ("X" mark slit will work the best.)



KAB SERIES

Install Instructions
Puncture 2 holes here for
KAB Series Seats (Weld Nuts).



3

Place the lock washer on the bolt then feed the bolt through the armrest mounting plate. Then place the spacers on the bolts.

4

Thread the bolts into the weld nuts in the frame using the punctured holes, and tighten by hand only (no power tools), alternating tightening until assembly is tight to the frame. Finish by tightening with a wrench. Do not over tighten as this may strip the weld nut in the frame.

For one seated individual. Maintenance Specialist is recommended. Please visit www.ultraseat.com for more information regarding this product.

KAB SERIES ARMRESTS INSTALLATION GUIDE