

ULTRA J SERIES ARMREST

INSTALLATION GUIDE

ULTRA J SERIES ARMRESTS

- Ultra "J" Series



Phone: 1-800-667-7328
Fax: 1-888-667-7328
www.ultraseat.com



ULTRA SEAT CORPORATION

Updated: 07/11/22

15001102

**Product in photo(s) may be different than purchased product,
For additional photos and information please visit
www.ultraseat.com*

1

Place the arm bracket over the holes and thread the nuts through the holes in bracket. Aligning the holes.

2

Tighten the nuts. Do not over tighten as this may strip the studs.



For one seated individual. Maintenance Specialist is recommended. Please visit www.ultraseat.com for more information regarding this product.

ULTRA J SERIES ARMREST INSTALLATION GUIDE